

# LOCKLATCH™

## INSTALLATION GUIDE

LockLatch™ fits any type of window or door, wood, metal, aluminium or PVC and can be installed whichever way it opens.

All you'll need is a drill and a screwdriver or pop rivet gun.



## WOOD & METAL




1. Remove the double-sided tape from the bottom of each footplate



2. Position the LockLatch™ on the frame or wall and if you need to drill into masonry use plastic wall plugs



3. Check that the window or door opens and closes and adjust if required



4. Mark the position for the holes



5. Remove the LockLatch™



6. Drill four 2mm pilot holes



7. Reposition the LockLatch™



8. Insert the four one-way screws



9. Done and secured!

## ALUMINIUM, PVC & METAL



1. Remove the double-sided tape from the bottom of each footplate



2. Position the LockLatch™ on the frame or wall and if you need to drill into masonry use plastic wall plugs



3. Check that the window or door opens and closes and adjust if required



4. Mark the position for the holes



5. Remove the LockLatch™



6. Drill four 5mm holes



7. Reposition the LockLatch™



8. Insert the pop-rivets



9. Done and secured!